

## **UFO High Bay Bird Guard Instructions Manual**

## INSTALLATION

**CAUTION:** To reduce the risk of electrical shock, turn off power supply before installation or servicing.

## **ACCESSORY LIST**



Bird Spike Kit x 2



Bracket x 1



Screw x 2

- 1. Remove the Hook and Nut from the fixture.
- 2. Secure the Bracket (1) to fixture with removed Hook and Nut.
- 3. Fix the Bird Spike Kits (2) on the Bracket with Screws (2).
- 4. Bend the Spikes as required.

