

**INSTALLATION**

1. Remove Screws and Washers (4) and separate the Upper Part from the Bottom Part.
2. Remove Clips (8) and Screws (8).
3. Feed Glass Frosted Lens (4) into the Bottom Part. The Lens are in the gap between Soft Stopper and Housing and close to Soft Stopper. Make sure the Smooth Surface of glass lens towards outside.
4. Secure Glass Frosted Lens (4) with these removed Clips (8) and Screws (8).
5. Replace the Upper Parts and secure it with removed Screws (4).

