

LATITUDE LED TROFFER Instructions Manual

/!\ CAUTION! Risk Of Electric Shock

/i Turn off all power prior to installation by switching off circuit breaker or removing fuse at fuse box.

Installaion requires knowledge of the lighting luminaires electrical systems. If not qualified, do not attempt installation and contact a qualified electrician.


NOTES

- 1.Indoor lighting only.
- 2.Before installation, ensure the LED panel is not damaged.
- 3.Don't stare at the LED luminous surface for long time.
- 4. Keep away from children, and ensure working electrical apparatus inaccessible to them.
- 5.No packages accessible to children, because they might be choked for playing, or eating the small accessories.
- 6.No covering, be away from fire or high-temperature substance.
- 7. Manufacturer reserves the right to offer no replacement or warranty to the led panels dissembled or repaired by users themselves.
- 8.Cut off power before cleaning the panels with dry cloth, use no chemical or corrosive substance.
- 9.Cut off power before installation.
- 10. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.


WIRE CONNECTION

Universal voltage driver permits operation at 120V thru 277V, 50 or 60 Hz.

- 1. Connect the voltage supply Line to our AC-L terminal
- 2. Connect the voltage Neutral supply to our AC-N terminal3. Connect the green/yellow ground lead to the supply ground lead



WATTAGE AND CCT SETTING






LATITUDE LED TROFFER Instructions Manual

INSTALLATION

RECESSED MOUNT (T-Grid Ceiling)

- 1. Turn off the power.
- 2. Remove the ceiling(s) at an appropriate location where the light fixture is to be installed. See Figure 1.
- 3. After securing the light fixture to the T-bar then secure the light fixture to the ceiling with aircraft cable or wires capable of sipporting 100lbs.minimum. See Figure 2.
- 4. Remove access cover plate and remove the necessary knockout. Connect cable wires with appropriate relief strain and wire connectors (not provided). See Figure 3.
- 5. Reinstall the access cover plate with removed screws. Make sure ALL wires are tucked into the housing and not get pinched by the cover. See Figure 3.








Figure 3